



How to register Receiver

Technical FAQ



Surveying | Aug 2024


Receiver Registration

We provide two ways to register receivers, one is through the receiver webpage and the other is through the controller and Landstar software


1. Controller registration

Steps:

- 1) Open the LandStar software. Connect the receiver to the controller via Bluetooth or Wi-Fi.
- 2) Click the Config option. Then select the Instrument info option.




- 3) Select the registration option after the expiration date or the expiration date of modeling



- 4) The software provides two ways to input the registration code, QR code, and manual input.

At the Activation code, manually enter the registration code or scan the QR code successfully, then click Activate to complete the registration



2. Webpage registration

Steps:


- 1) First use your computer or mobile phone to connect to the receiver's wifi (the name is the receiver's SN number)



- 2) Open the browser and enter the page with the URL 192.168.1.1.

(Noted: login account: admin, password: password)

- 3) After logging in, select the firmware option from the left options bar and click on GNSS Registration.
- 4) Input the registration code in the input field after the registration code. Then click Registration to complete the registration



Please note that the device code and function code use the same input box in the webpage, so you don't need to worry about the function code overwriting the original device code.

CHC Navigation

Building C, NO. 577 Songying Road,
Qingpu District, 201703 Shanghai, China

Tel: +86 21 542 60 273 | Fax: +86 21 649 50 963

Email: sales@chcnav.com | support@chcnav.com

Skype: chc_support

Website: www.chcnav.com