X-PAD Ultimate FAQ Series

FAQ: Disable Background Optimization

More FAQ's like this one are available here: [X-PAD FAQ Series]

Date: 2/15/2023   By: Mark Silver, ms@igage.com

Filename: FAQ_XPAD_BackgroundOptimization_002.docx

Thesis

X-PAD needs to be allowed unlimited device resources to run in the background so that it can continue to talk to the controlled instrument (GNSS, TPS) if you make a phone call or use another application.

There are two sections to this document:

One: Google Pixel Devices
Two: Samsung Devices

Method One: Google Pixel Devices

a.   Click and hold on the X-PAD desktop icon, then click on the little **(i) App info**
b.   Click on the Battery setting
c.   Set **Manage battery usage** to **Unrestricted**

Method Two: Samsung Devices

1. Click and hold on the X-PAD desktop icon:

Then click on the little "i" in a circle.

2. The X-PAD app settings are shown:

Click on the **Battery** item.

3. The **Battery** optimization settings will be shown:

Select **Unrestricted**.

4. On the left panel, click on 'Location':

Make sure **Location** is **ON**.
Click on **Location Services**.

5. Make sure that **Wi-Fi scanning** and **Bluetooth scanning** are enabled: